


TWINAX/TRIAX STANDARD & SUBMINIATURE LOOPING PLUGS



Standard Twinax/Triax Looping Plugs...

Handle: A=.625" B=1.20"	Impedance	Twinax
PLAIN	78Ω	LPTW-78
TEST POINT MONITOR	78Ω	LPTW2TP-78
TRB MONITOR	78Ω	LPTWA-78
PLAIN	124Ω	LPTW-124
TEST POINT MONITOR	124Ω	LPTW2TP-124
TRB MONITOR	124Ω	LPTWA-124

Handle: A=1.00" B=1.57"	Impedance	Twinax
PLAIN	78Ω	LPLTW-78
TEST POINT MONITOR	78Ω	LPLTW2TP-78
TRB MONITOR	78Ω	LPLTWA-78
PLAIN	124Ω	LPLTW-124
TEST POINT MONITOR	124Ω	LPLTW2TP-124
TRB MONITOR	124Ω	LPLTWA-124

Handle: A=.625" B=1.20"	Impedance	Triax
PLAIN	50Ω	LPTR-50
TRB MONITOR	50Ω	LPTRA-50
PLAIN	75Ω	LPTR-75
TRB MONITOR	75Ω	LPTRA-75

Handle: A=1.00" B=1.57"	Impedance	Triax
PLAIN	50Ω	LPLTR-50
TRB MONITOR	50Ω	LPLTRA-50
PLAIN	75Ω	LPLTR-75
TRB MONITOR	75Ω	LPLTRA-75

LOOPING PLUG HANDLE EXAMPLES:

TRS/TRB Monitor



Plain Handle



Test Point Monitor




Subminiature Looping Plugs...

Handle	Impedance	Twinax
BLUE	78Ω	LPTWM-78
BLUE TRS JACKS	78Ω	LPTWMA-78
BLUE TEST POINT	78Ω	LPTWM2TP-78

BLUE	124Ω	LPTWM-124
BLUE TRS JACKS	124Ω	LPTWMA-124
BLUE TEST POINT	124Ω	LPTWM2TP-124

Handle	Impedance	Triax
YELLOW	50Ω	LPTRM-50
YELLOW	75Ω	LPTRM-75



LPTWM-Z SHOWN
Z = IMPEDANCE