



Molex Japan Co., Ltd.

Instruction Manual No.	
IS-0029E	
Issued	1987-02-25
Revised	
Rev.	0

OPERATING MANUAL

Extractor for 1.25mm Pitch Crimp Terminal Series Tool No.: 57072-6000

1. Introduction

This document is prepared so that the tool is properly used.

Please take the time to read this manual, making sure you understand the operating procedures described herein before attempting to operate the tool.

2. Specifications

	Receptacle	Board-in
Applicable Housing Number	51021-**00	51022-**00
Applicable Terminal Number	50058, 50079	50061, 50080

3. Operating Steps

No	Operating steps	Explanation figure
1	As shown in the right figure, turn up the display part of "Molex" and hold the extraction tool.	
2	Turn up the lance part of housing and hold it by the opposite hand. Next, perform the followings as shown in the right figure. A) Bend a wire to the bottom. B) Insert a tool in the back.	
3	Where a tool is inserted, grip a wire and a tool, as shown in the right figure, and draw out in the direction of an arrow simultaneously.	