# ASAHI KASEI

[AKD4309B]





Figure 1 . AKD4309B Block diagram

'97/05



י 2

ı

#### [AKD4309B]

## ASAHI KASEI

#### External Analog Filter

The AK4309B includes the successive of single-ended outputs, so it does not require any external components. The BNC connectors on the board supplies the analog outputs of AK4309B directly. The output level of AK4309B is about 1Vrms(AVDD=5V).

## Power Supply and its Decoupling

AVDD and DVDD to the AK4309B are decoupled separately in order to minimize the effect of the digital noise. A system analog supply is fed to AVDD and it is also fed to DVDD by way 10  $\Omega$  resistor from AVDD. Decoupling capacitors should be connected to AK4309B as near as possible, particularly with the ceramic capacitor to the VREF pin.

## Operation Sequence

(1) Set up the power supply lines.  $AVDD=DVDD=+4.5 \sim 5.5 V$ , AVSS=DVSS= 0 V

The evaluation board shorts J1, and it is used a common AVDD and DVDD.

② Set up the evaluation modes and jumper pins (See next item).

Be careful for the operating voltage when use DIR or ROM board.

- ③ Power on, and push reset switch after that.
- ※ SW2 resets the AK4309B during operation.

Set-up of the Evaluation Modes and Jumper Pins

#### 1. Evaluaion Mode

Applicable Evaluation Mode

\* Be careful for the operating voltage when use DIR or ROM board.

- ① DIR (Optical link)
- 2 Ideal sine wave generated by ROM data
- ③ Using AD converted data
- ④ All interface signals including master clock are fed externally

# 1 DIR(CS8412)

PORT2 is used. DIR generates CLK, BICK and LRCK from the received data through optical connector (TORX174). Used for the evaluation using CD test disk. Nothing should be connected to PORT1.




Figure 2. Jumper Set Up(DIR)

## ASAHI KASEI

#### 2 Ideal sine wave generated by ROM data

Digital signals generated by AKD43XX are used. PORT1 is used for the interface with AKD43XX. Master clock is sent from AKD4309B to AKD43XX and LRCK, BICK, SDATA are done from AKD43XX to AKD4309B. In case of using external clock through a BNC connector, selects EXT on J6(CLK) and shorts J7.




Figure 3. Jumper Set Up(ROM)

## ③ Using AD converted data

It is possible to make evaluation in the from of analog inputs and analog outputs by interfacing with various AKM's A/D evaluation boards (AKD5391, AKD5390, AKD5352/1, AKD5350 and AKD5330) with PORT1. In case of using external clock through a BNC connector, select EXT on J6(CLK) and short J7.




Figure 4. Jumper Set Up(A/D)

All interface signals including master clock are fed external
Under the following set-up, all external signals cloud be fed through PORT1.





Figure 5. Jumper Set Up

## ASAHI KASEI

# 2. BIT CLK ( BICK ) Set-up






Either 32fs or 64fs could be selected. Figure shows 64fs example.

# 3. CKS Set-up

Figure 7



- The Function of the Others
  - (SW1) It is not needed for evaluation of AK4309B.
  - [SW2] It resets the AKD4309B. Put the down position during conversion.
  - [LE1] It indicates whether the input data is pre-emphasized or not. LED turns on when the data is pre-emphasized.
  - [LE2] It monitors VERF pin of the CS8412. LED turns on when some error has occurred to CS8412.

5 -

# AK4309B Measurement example

	Table 1. AK4	1309B(Use 24pi)	n SSOP socket)	Measurement results
--	--------------	-----------------	----------------	---------------------

		Measurement Filter
THD+N	-86.0dB	20kLPF
DR(-60dB)	86.9dB	20kLPF
	90.2dB	20kLPF + A-Weight
S/N	87.6dB	20kLPF
	91.0dB	20kLPF + A-Weight

[Conditions]

Measurement unit	: ROHDE&SCHWARZ UPD04	
Device	: 20pinSSOP	
Interface	: DIR	
MCLK	: 256fs	
Digital input data	: 16bit	
fin	: 1kHz	
Temperature	: Room temperature	
(FFT plot)		
Points	: 8192	
Averaging	: 16	




Fig.1 FFT(0dB)




Fig.2 FFT(-60dB)




Fig.3 FFT(noise floor)




Fig.4 FFT(noise floor : ~100kHz)




Fig.5 THD+N vs Frequency




Fig.6 THD+N vs Input Level




Fig.7 Linearity




Fig.8 Frequency Response






Fig.9 Crosstalk




AKD4310 parts layout




# <KM046302>


'95/10




AKD4310 solder plane



<KM046302>



AKD4310 ground plane



<KM046302>

'95/10

# **IMPORTANT NOTICE -**

- These products and their specifications are subject to change without notice. Before considering any use or application, consult the Asahi Kasei Microsystems Co., Ltd. (AKM) sales office or authorized distributor concerning their current status.
- AKM assumes no liability for infringement of any patent, intellectual property, or other right in the application or use of any information contained herein.
- Any export of these products, or devices or systems containing them, may require an export license or other official approval under the law and regulations of the country of export pertaining to customs and tariffs, currency exchange, or strategic materials.
- AKM products are neither intended nor authorized for use as critical components in any safety, life support, or other hazard related device or system, and AKM assumes no responsibility relating to any such use, except with the express written consent of the Representative Director of AKM. As used here:
- (a) A hazard related device or system is one designed or intended for life support or maintenance of safety or for applications in medicine, aerospace, nuclear energy, or other fields, in which its failure to function or perform may reasonably be expected to result in loss of life or in significant injury or damage to person or property.
- (b) A critical component is one whose failure to function or perform may reasonably be expected to result, whether directly or indirectly, in the loss of the safety or effectiveness of the device or system containing it, and which must therefore meet very high standards of performance and reliability.
- It is the responsibility of the buyer or distributor of an AKM product who distributes, disposes of, or otherwise places the product with a third party to notify that party in advance of the above content and conditions, and the buyer or distributor agrees to assume any and all responsibility and liability for and hold AKM harmless from any and all claims arising from the use of said product in the absence of such notification.