

Jewel®



Wristband Circumference - 5.5" - 13"

Jewel® MagSnap Wrist Straps meet or exceed the requirements of ANSI/ESD S20.20 and ANSI/ESD S1.1 including section 5.4 Breakaway Force "With the ground cord connected to the cuff in a normal manner, a force of $\geq .45$ kg (1 lb) but ≤ 2.3 kg (5 lb) applied to the ground cord, in the normal disconnect direction, shall be required to separate the ground cord from the cuff."

Per ANSI/ESD S20.20 Paragraph 6.2.2.1. Personnel Grounding Requirements "All personnel shall be bonded or electrically connected to ground or contrived ground when handling ESD sensitive items. When personnel are seated at ESD protective workstations, they shall be connected to the common point ground via a wrist strap system."

"At first glance, the ground cord appears to be a relatively simple assembly. However, the design requirements are considerable, given the wide range of user applications and the durability requirements of constant tugging, flexing, and dragging over the edge of workstation tops and equipment chassis."

(ESD Handbook TR20.20 paragraph 5.3.2.2.2 Wrist Strap Ground Cord)

NOTE: Complete wrist strap kits include an alligator clip. Wrist strap kits include an alligator clip for occasions when a grounded banana jack is not available. However, "Wrist strap ground cords must be connected to a groundable point or an equipotential bonding point. Do not connect to a snap on a dissipative mat unless it is the groundable point for the mat. Do not clip a wrist strap to the edge of a dissipative mat." (ESD Handbook TR20.20 section 5.3.2.7)

ESD Handbook TR 20.20 paragraph 5.3.2.4.4 Test Frequency "Because wrist straps have a finite life, it is important to develop a test frequency that will guarantee integrity of the system. Typical test programs recommend that wrist straps that are used daily should be tested daily. However, if the products that are being produced are of such value that knowledge of a continuous, reliable ground is needed, and then continuous monitoring should be considered or even required"

Continuous Monitors pay for themselves improving quality, productivity, eliminating wrist strap daily testing and test result logging. Per ESD-S1.1 paragraph 6.1.3 Frequency of Functional Testing "Daily (Wrist Strap) testing may be omitted if constant monitoring is used."

• **Revolutionary magnetic interconnect technology**

Creates magnetic connection between wristband and coil cord; meets ANSI/ESD S20.20 AND ESD S1.1, including disengagement force test (1-5 lbs). More consistent disengagement force than standard 4 mm designs.

• **More reliable design**

Magsnap revolutionary design provides consistent retention and release performance.

• **Premium metal expansion wrist strap**

Comfortable, designed not to pinch or pull hair

• **Durable metal band**

Long wearing, easy to clean

• **Superior contact with skin**

For reliable removal of generated static charges

• **Non-flaking or scratching laminated insulator on all external surfaces**

Protects wearers from electrical hazards; provides many years of product life

• **Medical grade 300 series stainless steel used for all metal parts**

Eliminates allergic skin reaction for most people

• **UL Listed**

Note: this product is not recommended for use on equipment with operating voltage exceeding 250 VAc.

CAUTION: the ESD series is for electrostatic control. It will not reduce or increase your risk of receiving electric shock when using or working on electrical equipment. Follow the same precautions you would use without wrist straps, including:

- Make certain that equipment having a grounding type plug is properly grounded.
- Make certain that you are not in contact with grounded objects other than through the ESD Series.

• **Date coded**

Providing lot tractability to ensure quality control

• **Superior resistor connection strain relief**

Superior reliability. Greatly exceeds esD s1.1 Bending Life test. tested at over 1,000,000 cycles vs. the 16,000 requirement

• **Covered by one or more of the following patents:**

Wristband: 5,036,423; 5,568,351 coil cord: 5,951,337

• **Superior warranty**

See details of 1 year Limited Warranty at <http://www.desco.com/Warranty.aspx>

• **Made in America**

Meets ESD S1.1 cuff resistance interior =100 kilohms (1 x 10E2 ohms)

Meets ESD S1.1 cuff resistance exterior =10 megohms (1 x 10E7 ohms)

ITEM	DESCRIPTION	COLOR
09186	Jewel® MagSnap Adjustable Metal Wristband	Onyx
09187	Jewel® MagSnap Adjustable Metal Wrist Strap with 6 ft Coil Cord	Onyx
09188	Jewel® MagSnap Adjustable Metal Wrist Strap with 12 ft Coil Cord	Onyx
09195	Jewel® MagSnap Adjustable Metal Wristband	Emerald
09196	Jewel® MagSnap Adjustable Metal Wrist Strap with 6 ft Coil Cord	Emerald
09197	Jewel® MagSnap Adjustable Metal Wristband	Sapphire
09198	Jewel® MagSnap Adjustable Metal Wrist Strap with 6 ft Coil Cord	Sapphire
09199	Jewel® MagSnap Adjustable Metal Wrist Strap with 12 ft Coil Cord	Sapphire
09201	Jewel® MagSnap Adjustable Metal Wristband	Red and Blue

See Drawing [09180](#) for details on Jewel® MagSnap Coil Cords

Improve wrist strap contact with Reztore™ ESD Hand Lotion.



Made in America

DESCO

Jewel® MagSnap Adjustable Metal Wrist Strap

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com
PHONE (909) 627-8178
DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407
PHONE (781) 821-8370

**DRAWING
NUMBER**
09186

DATE:
January
2010

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Desco:

09187 09186